


LOAD CELL CALIBRATOR



Home Screen

A versatile machine that facilitates both compression and tension calibrations. The design contributes to accurate calibrations by assuring axial loading while eliminating all friction and machine losses.



Display vales of master, actual and deviation value. Graphical representation of sensor vs time



Calibration Setting Screen

04-11-2016 Memory Status : 1.1 MB Not Logging No Pendrive Connected 17:38:51

Home

Channel 1 Calibration

Name : Ch 1 Channel 1 Analog I/P :

Input type : Load Decimal : 0

Unit : Kg Conversion : Kg

Low Voltage : 0 High Voltage : 0

Low Value : 0 High Value : 0

Save Settings

Channel 1

TestSetup

Calibration setting of load cell and its units conversion

Specifications are subject to change without notice

www.seetharam.in



LOAD CELL CALIBRATOR



Setting Screen

04-11-2016 Memory Status 1.1 MB Not Logging No Pendrive Connected 17:39:07

Settings

Home

Setup

Database

Help

Power

Enter File Name : TEST New File

Test No : 1

- Manual
- Auto

Save Settings

Channel 1

TestSetup

User Friendly Customizable Test report management



Screen

04-11-2016 Memory Status 1.1 MB Not Logging No Pendrive Connected 17:39:29

List of Files :

List of Tests :

ID	datetime	load	master	deviation	testno	masterval
1	17-03-	0	0	0	0	0
2	17-03-	0	0	0	0	0
3	17-03-	0	0	0	0	0
4	17-03-	0	0	0	0	0
5	17-03-	0	0	0	0	0

ID	datetime	load	master	deviation	testno	masterval
1	17-03-	0	0	0	0	0
2	17-03-	0	0	0	0	0
3	17-03-	0	0	0	0	0
4	17-03-	0	0	0	0	0
5	17-03-	0	0	0	0	0

Home

Setup

Database

Help

Power

Refresh

Send Data

Send Database

Delete File

Plot Graph

Hassle free database management

Specifications are subject to change without notice

www.seetharam.in

